

# **BIO-METRIC DEVICE MODEL**

## **Option - 1 ( compatible on Internet Explorer version 8 and below )**

NITGEN bio metric solutions

Name : Hamster DX

Model : HFDU06

DC 5V 120mA

## **Option - 2 ( compatible on Internet Explorer version 11 and above )**

NITGEN bio metric solutions

Name : eNBioScan-C1

Model : HFDU08

DC 5V 180mA

Vendor Details: Mr.Jagannath.V

Landline: 080 41289900

Mobile: 9844078287

# **BIO-METRIC DEVICE CONFIGURATION STEPS**

**Step 1:** Install Device Driver.

**Step 2:** After Installation, Download the dll file from below URL

<https://exm.campusuite.in/Biometricfiles/system32/NBioBSPCOM.dll> and save the files to C:/window/System32

**Step 3:** Next, Download the dll file from below URL

<https://exm.campusuite.in/Biometricfiles/SySWOW64/NBioBSPCOM.dll> and save the Files to C:/window/Syswow64

**Step 4:** Then, Go to Programs→run→cmd→Right Click and select run as Administrator and command prompt will appear and then Execute the Given below commands

Command1: cd Press enter key (give space and then Press enter key)

Command2: cd:\> cd windows (Press enter key)

Command3: cd:\windows> cd system32 (Press enter key)

Command4: cd:\windows\system32> regsvr32 NBioBSPCOM.dll (Press enter key and you will get Successful Message)

**Step 5:** Go to Programs→run→cmd→Right Click and select run as Administrator and command prompt will appear and then Execute the Given below commands

Command1: cd Press enter key (give space and then Press enter key)

Command2: cd:\> cd windows ( Press enter key)

Command3: cd:\windows> cd SysWOW64 (Press enter key)

Command4: cd:\windows\SysWOW64> regsvr32 NBioBSPCOM.dll (Press enter key and you will get Successful Message)

**Step 6:** Go to Internet Explorer browser → Settings → Internet Options

Select Internet (1<sup>st</sup> Icon under security tab) → Click on Custom level tab → under all heading check/select Enable option by scrolling till end → Click on Ok

Select Local Internet (2<sup>nd</sup> Icon under security tab) → Click on Custom level tab → under all heading check/select Enable option by scrolling till end → Click on Ok

Select Trusted Site (3<sup>rd</sup> Icon under security tab) → Click on Custom level tab → under all heading check/select Enable option by scrolling till end → Click on Ok

Select Restricted Site (4<sup>th</sup> Icon under security tab) → Click on Custom level tab → under all heading check/select Enable option by scrolling till end → Click on Ok

## Web cam

Please find the URL to download the **Adobe flash player for Webcam**  
<https://get.adobe.com/flashplayer/>  
<https://adobe-flash-player.en.softonic.com/download>